

TBMS Motorized Honeycomb

TBCL-24 Changing a motor channel after programming

To change the channel of a motor after it has been programmed, do the following:

Start with the channel that currently works the shade

Press P2 – Shade will jog

Press P2 – Shade will jog

Select the desired new channel

Press P2 – Shade will jog

NOW THE SHADE WILL WORK ON BOTH CHANNELS

Select the desired channel to keep

Press P2 – Shade will jog

Press P2 – Shade will jog

Select the desired channel to delete

Press P2 – Shade will jog

The channel has now been deleted