

# **TBMS Motorized Honeycomb TBCL-24 Speed Adjustment**

## **To increase the motor speed:**

After the motor is fully programmed, hold the Stop + the ↑ arrow for approximately 2 seconds (until the shade jogs). This will increase the speed by one level.

Release the buttons and repeat the process until the desired speed is reached.

When the shade will no longer jog while holding the Stop + the ↑ arrow, the maximum level has been reached.

## **To decrease the motor speed:**

After the motor is fully programmed, hold the Stop + the ↓ arrow for approximately 2 seconds (until the shade jogs). This will decrease the speed by one level.

Release the buttons and repeat the process until the desired speed is reached.

When the shade will no longer jog while pressing the Stop + the ↓ arrow, the slowest level has been reached.

**\*\*\*\*\*PLEASE BE ADVISED THAT AS THE SPEED IS INCREASED,**

**SO IS THE NOISE LEVEL\*\*\*\*\***