

TimberBlindMetroShade

MS30 Programming

These directions are for programming a motor from a factory default state. If the shade has been programmed and other adjustments need to be made, additional directions will be at the end of this document. Please read entire document before programming.

STEP 1 To pair a remote to a shade

- 1.Press the programming button on the motor for 1 jog& beep.
 - 2.Press P2 on the remote. (Shade will jog& beep)
 - 3.Press P2 on the remote. (Shade will beep)
 - 4.Press up or down arrow. (Shade will jog& beep 5 times)
- The remote will now work with the shade.

STEP 2 Limit Setting Mode

- 1.Press P2 on the remote. (Shade will jog& beep)
- 2.Press the up arrow on the remote. (Shade will jog& beep)
- 3.Press P2 on the remote. (Shade will jog& beep 4 times to confirm that you are in limit setting mode). You can now set the limits.

STEP 3 Setting limits

1. Move shade to the desired Upper/Lower position, stop the shade (Shade will beep) and continue to hold the stop button until the shade jogs. The limit is now set.
2. Move shade to the desired Upper/Lower position, stop the shade (Shade will beep) and continue to hold the stop button until the shade jogs. The limit is now set.
- 3.If limits need to be adjusted after setting, go back to Limit setting Mode and follow SettingLimits

STEP 4 Setting 3rd Limit, Intermediate Position

- 1.Move shade to the desired intermediate position.
 - 2.Press P2 on the remote. (Shade will jog& beep)
 - 3.Press stop on the remote. (Shade will jog& beep)
 - 4.Press stop on the remote. (Shade will jog& beep 3 times)
- The intermediate stop is set.
To activate 3 limit, press the stop button for approximately 2sec. Blind will move to the set position.

STEP 5 To remove 3rd Limit, Intermediate Position

- 1.Press stop button for about 5 sec, shade will move to intermediate position.
 - 2.Press P2 on the remote (Shade will jog& beep)
 - 3.Press stop button on the remote. (Shade will jog& beep)
 - 4.Press stop button on the remote. (Shade will jog& beep 3 times)
- 3rd limit is now removed.

STEP 6 Adding a remote

Start with the remote that currently works the shade.

- 1.Press P2a (Shade will jog& beep)
 - 2.Press P2a (Shade will jog& beep)
 - 3.Press P2b (Shade will jog& beep 7 times)
- P2a = Working remote, P2b = Remote to add

STEP 7 Removing a remote

Start with the remote that currently works the shade.

- 1.Press P2a
 - 2.Press P2a
 - 3.Press P2b
- P2a = Remote to keep, P2b = Remote to delete

STEP 8 Replacing a lost remote

If shade has been previously programmed but the remote has been lost:

- 1.Press the programming button on the motor for 1 jog& beep.
 - 2.Press the up & down arrows on the new remote.(Shade will jog& beep)
- The new remote has been added to the shade. The shade will have the same settings as with the previous remote.

What motor jogs mean

- 1.A single jog = To pair a remote to a new motor or replace a lost remote.
- 2.Two jogs = Reverse motor direction.
- 3.Three jogs = Complete factory reset.

Additional Information:

Location of P2 on remote



Location of reset button

