

# **TBMS SYSTEM**

## **Multi/Group Channel Programming**

### **To add a group channel**

Start with the current working channel (Can't be zero)

Press P2 – Shade will jog

Press P2 – Shade will jog

Select the channel to add to the group

Press P2 – Shade will jog

**Group channel has now been added.**

### **To remove a shade from group channel**

Start with channel to keep

Press P2 – Shade will jog

Press P2 – Shade will jog

Select channel to be deleted

Press P2 – Shade will jog

**Group channel has now been removed.**

**Zero will still operate everything on the remote (Multi Channel Remote) It is built into the programming of the motor and can't be changed.**